

Bed Edger

Operating Instructions:

- 1. Inspect area to be cut and remove all foreign objects.
- 2. Make sure no underground utilities are in the area of operation.
- 3. Disengage all clutches before starting the engine.
- 4. Turn gas on.
- 5. Adjust Choke
- 6. Adjust Throttle
- 7. Pull backwards slowly while starting out and increase as you get used to the machine.

Safety Instructions:

- 1. Never allow children or persons not trained in the use of the machine to use or service it.
- 2. Always concentrate focus on task at hand, avoid distractions.
- 3. Never leave machine unsupervised while running.
- 4. Only use machine in daylight or other well lit conditions.
- 5. Check safety decals and make sure all bolts are properly tightened before each use.
- 6. Never attempt to make any adjustments to cutting depths while machine is running.
- 7. Make sure animals and people are at least 15' away while operating.
- 8. Find and make sure you know where all buried lines (Electrical, Water) are located before cutting or digging.
- 9. Never intentionally run over foreign objects.
- 10. Wear protective foot wear.
- 11. Never allow children to operate machine.
- 12. Do not operate in a confined space. Fumes will cause sickness or death.
- 13. Do not use the machine on grades of more than 20 degrees.
- 14. Do not use on machine on any surface other than earth, dirt or ground.
- 15. Do not operate while under the use of drugs or alcohol.
- 16. Do not over load machine.