

**STANDARD TOOLS FOR INSTALLATION
&
THEIR FUNCTIONS**

PHOMI

TOOL

MEASURING TAPE



REFERENCE IMAGE

FUNCTION

FOR SITE
MEASUREMENTS

WALL SURFACE
FLATNESS CHECKING
TOOL



FOR
CHECKING
SURFACE
FLATNESS

TOOL

REFERENCE IMAGE

FUNCTION

TILE CUTTER



TO CUT
MCM PANELS

GRINDER MACHINE



TO CHAMFER EDGES OF
MCM PANELS AT
45 DEGREES

TOOL

REFERENCE IMAGE

FUNCTION

MIXER PAIL/ DRUM



TO MIX THE SUITABLE
ADHESIVE

TOOL

REFERENCE IMAGE

FUNCTION

SPINNER



TO
HOMOGENOUSLY MIX THE
ADHESIVE

TOOL

REFERENCE IMAGE

FUNCTION

RUBBER HAND
GLOVES



TO WEAR WHILE
LAYING MCM PANELS

SQUARE TROWEL



TO SPREAD THE ADHESIVE ON
SUBSTRATE

TOOL

V— NOTCHED
TROWEL

REFERENCE IMAGE



FUNCTION

TO PROVIDE
STANDARD
GROVES AND
THICKNESS
TO THE ADHESIVE
LAYER

TROWEL WITH PAD



TO PRESS AND THUMP THE
MCM PANELS & TO REMOVE
THE AIR BETWEEN MCM
PANELS AND THE SUBSTRATE,
TO ENSURE THE EVEN SREAD
OF ADHESIVES

TOOL

COTTON CLOTH/SPONGE

REFERENCE IMAGE



FUNCTION


TO CLEAN THE SURFACE
OF MCM PANELS OF ANY
ACCESS ADHESIVE OR
DUST MARKS

TOOL

REFERENCE IMAGE

FUNCTION

SPACERS



TO MAINTAIN
UNIFORM GROVES
BETWEEN MCM PANELS

MASKING TAPE



TO APPLY ON THE MCM
PANELS EDGES BEFORE
FILLING THE GROUT TO
PROTECT SPREADING ON
MCM PANELS

TOOL

PLASTIC CONE

REFERENCE IMAGE



FUNCTION

TO FILL THE GROUTS

TOOL

REFERENCE IMAGE

FUNCTION

SEALANT GUN



TO FILL THE GROUTS

METAL RODS



TO UNIFORMLY SPREAD
THE GROUTS

TOOL

SCRAPPER

REFERENCE IMAGE



FUNCTION


TO SCRAPE OF THE
EXCESS GROUT
SPREADING ON MCM
PANELS

TOOL

REFERENCE IMAGE

FUNCTION

PAIN**T** BRUSH



TO FILL GROU**T**S / COLOUR AT HAIR LINE JOINTS ,IF REQUIRED

ROLLER



TO APPLY PROTECTIVE COATINGS ON MCM PANELS WHEN INSTALLED IN WET AREAS / HIGH TRAFFIC AREA / FLOORING APPLICATION

NOTE : THIS PROTECTIVE COATING SHOULD BE APPLIED ON MCM PANELS BEFORE INSTALLATION. ALSO, THE MCM SURFACE SHOULD BE DRY AND FREE FROM DUST