



Instruction Manual

## Contents



Spice Spinner Base (A) (X1)




Upper Level Platform (B) (X1)



Base Pillars (C) (X3)



Inner Pillars(D) (X3)



## Important Safety Instructions


#### To protect against the risk of injury, follow the basic safety precautions below:

- Read all instructions.
- Do not load more than five pounds of items on the Upper Level Platform. Overloading the Upper Level Platform may cause the Spice Spinner™ to tip and/or damage the unit.
- Once pillars are installed, do not remove as the locking tabs will no longer lock into upper and lower base.


## Care and maintenance

Clean with damp cloth or sponge.


#### **Features**




# Assembling your Spice Spinner ™




1) Remove the Spice Spinner ™ contents from the box and lay out the components on a flat surface.



2) Hold the longer Base Pillar(C) in a vertical position making sure the holes are on top, firmly press all 3 pillars into the cavities of Spice Spinner ™ Base (A). Ensure Base Pillars "snap" into the socket.



3) Flip the Upper Level Platform (B) upside down as shown in the image. Making sure the round locking buttons are facing upright, firmly press all 3 Inner Pillars (D) into the socket of the Upper Level Platform (B).



4) Align the Base Pillars(C) with the Inner Pillars (D). Once the pillars are alligned, press the locking button on the Inner Pillar(D), and push down on the Upper Level Platform lightly until you hear a snap. Repeat step to remaining 2 pillars.





©2020 ALLSTAR INNOVATIONS

Spice Spinner™ is a trademark of ALLSTAR INNOVATIONS

Licensed By: Simple Solutions Enterprises, LLC.

Distributed by ALLSTAR INNOVATIONS

Hawethorne, NY 10532

Made in China.

Patent Pending.