

How to change the time on a digital tachograph for Siemens tachographs



When in the main menu, press the up arrow until you reach 'entry - vehicle' then press 'OK'



From here press the up arrow until you see 'vehicle local time', and select 'OK'



The time changes in 30 minute intervals, so press the up/down arrow until the time displayed is correct. To save press 'OK'



Press the back arrow (on the left) to leave the 'vehicle entry' menu



Press 'OK' when asked if you want to leave main menu, and the local time has been changed.