

AeroSouth

User Guide: Main Sheet Line Guide Clip

Purpose: Prevent main sheet from tangling on crew during tacking and gybing.

Material: PLA or PETG, fabricated by 3D Printing. As with most plastics, these will degrade over time when exposed to UV and water. When not in use, best is to store parts in a dark, dry location. There is no need to remove from the sailboat's rig.

Installation:

1. Gently pull the two sides of the clip apart, just enough to allow the sheet line to enter the guide hole through the slotted opening.
2. Gently push the clip onto the boom. Best is to angle the clip so its rounded edges slip around the boom.
3. Ideally, three clips should be used between pairs of sail grommets.
4. Clips work with both types of sail attachment, through plastic sail rings or line.

Note: When the clip is pushed onto the boom, some cracking of the internal plastic structure may be heard. This is normally minor and does not affect performance. Excessive tension on the clip's sides however may lead to breakage. AeroSouth will switch to more robust injection-molded parts when production volumes allow.



Have Questions or Comments? Contact us at:

AeroSouth

3406 7LKSW, West End, NC 27376

Attn: Kent Misegades, President and Owner, kent@aerosouth.net, 910-568-2580

ALL AEROSOUTH PRODUCTS ARE ENGINEERED AND PRODUCED IN NORTH CAROLINA, USA!