

PUMP CUP INSTALLATION INSTRUCTIONS

A new pump plunger cup, garter spring (when needed), and an assembly tool is included in this repair kit. Replacing the old pump cup and garter spring with new fuel resistant components and reusing the original pump plunger stem and delayer spring ensures proper height adjustment. Follow the illustrated instructions carefully. **Note: A complete pump plunger assembly may be purchased from your supplier if you prefer, or you have broken button tabs and cannot repair your existing pump plunger assembly.**

Caution:

