

Set Up Checklist

Outside the RV

*If camping at a site that does not have water hookups, fill up potable water tank first

- Inspect site for slide out/awning clearance, distance to water/electric hookups.
- With the RV attached to the tow vehicle, level side to side.
- Chock tires and detach RV from the tow vehicle.
- Place large wood block under tongue jack and level front to back..
- Lower stabilizer jacks. Wood support blocks are available if needed.
- Make sure breaker is off at the site's electrical post. Attach power cord, then turn breaker on.
- Attach blue hose to site spigot. Turn on water.
- Attach sewer hose to the drainage port. Leave valves closed until tanks are full or when departing.
- Open door ALL the way. Lower steps and check to see if legs are appropriate height so door has clearance to open without rubbing the top of the steps.

Inside the RV

- *If using the potable water tank, turn on water pump. ***Not needed when site has it's own water source.**
- Turn on water heater. Select "electric" if your site has it's own power source.
- With an outside spotter, open slide. Slide must be all the way in or all the way out, do not stop half way.

Basic troubleshooting:

- Can't get hitch off tow vehicle? Raise the tongue jack all the way back down, then up again.
- Air conditioning stopped working? May have overloaded the site's power. Check to see if the breaker at the site's electrical pedestal needs to be flipped back on.
- Microwave or TV stopped working? May have overloaded the GFI. Reset switch is on the outlet in the bathroom.
- Oven won't light? Turn knob to "pilot", hold down for 5-10 seconds before activating the ignitor switch.