

Echolink DTMF Functions

EchoLink can be configured to accept commands through the local receiver using DTMF tones (TouchTones). These commands are used to enable or disable the link, or to connect or disconnect a station on the Internet.

Each command consists of a sequence of digits (or the special keys *, #, and A through D).

The table below lists DTMF commands.

Command	Description	Default
Connect	Connects to a station on the Internet, based on its node number.	Node number
Call CQ	Puts EchoLink in Call CQ mode, to try to connect to another station also calling CQ.	27
Disconnect	Disconnects the station that is currently connected. If more than one station is connected, disconnects only the most-recently-connected station.	#
Disconnect All	Disconnects all stations.	##
Status	Announces the callsign of each station currently connected.	08

Connect

The default for the Connect command is to simply enter the node number to which you wish to connect.