




Ignite WiFi™ Hub comes
exclusively with Ignite
Internet or Ignite TV™
bundles






How to split my Rogers WiFi to
2.4GHz and 5GHz?




Powered by the
Ignite WiFi™
Gateway



Download APP
Ignite Wifi Hub



Complete The Basic Settings According To The APP Guidelines




Click "Connect"




smarth
[See Network](#)




Click "See Network"





Click “Settings” on the top right



Step 1: Tick the upper right corner

Step 2: Manually add a 5.0

Step 3: Click"Apply Changes

18:57



Changing WiFi Settings

Please give us a moment.

19:08



My Network



2.4 GHz Network
smarth

5 GHz Network
smarth5.0

[Show Passwords](#)



Gateway
Online



Expand Your WiFi Coverage

[Learn More](#)

More

Advanced Settings



Overview



Connect



People



More

Configuration is successful