





2 Gang Smart Switch User Guide

Notes Before Installation

- 1. Wi-Fi Only support a 2.4GHz network (802.11 b/g/n)
- 2. Neutral wire Required.
- 3.basic electrical wiring knowledge or experience required, or please consult
- a professional electrician
- 4. Never connect the neutral wire to any switch wires
- 5.ON/OFF Button also can be used as reset button, long press to reset your smart switch
- to factory defaults. Only do this if you are sure you want to erase all your settings



Safety Notice:



- Please use it only when it's installed with RCD or current leakage protector at home
- A neutral wire is needed to power the switch.




Installation Guide

Step 1

Turn off circuit breaker


Find your light's control in your circuit breaker and turn it off, Then make sure the power is off by flipping secured with a wire nut. Do you have a neutral wire? your switch a few times.



Step 2

Find the neutral wire

In the wall cassette. look for one or more white wires




If you can't find neutral wire Please change another wall cassette. to find a neutral wire, if you really can't find out a neutral wire in your wall cassette. please contact professional electrician to help you.

2

Step 3

Label your wires

Mark or record the corresponding line before removing the old switch



Usually:


White represents the neutral line Black represents the fire line Green or yellow or a single bare copper wire representing the ground wire

The above is for reference only and cannot be used as a standard.

Step 4

Install switch

Use wire-nuts to connect the switch wires to your home wires, following the diagram. Be careful to match line and load wires. Then remove the stickers, screw the switch into the wall. And attach the faceplate.






STEP.5

Turn on circuit breaker


Turn on your switch's power from the circuit breaker. Press the switch a few times to make sure it works.



STEP.6

Check the Wi-Fi light
Tap NEXT when the Wi-Fi indicator light blinks

Indicator light rapidly blinks (2 times per second)



4

Install the "MySmartH"APP

Step A .Find out "MySmartH" app in Apple app store, Google Play, or scan the QR code below and install it.



The free app"MySmartH" is compatible with mobile devices the support IOS8.0 above, Android 4.4 above

Step B. Enter the register interface, input the email address/phone number for getting the verification code to register an account. Please just login if you already have a MySmartH account.



1.Set Up Router



The router supports the 2.4GHz WiFi (doesn't support the 5GHz), and is connected to the WiFi network. Please set the parameters of the router before connecting the WiFi network, and record the SSID and password of your WiFi.

2.Turn On Your Smartphone's Bluetooth






Turn on your smartphone's Bluetooth.




Step C:Add the switch to MySmartH APP

Note: This smart switch can only support 2.4G network and cannot work with 5.0G network. please check if your home network is 2.4G and make sure that your phone has been connected to your WI-FI

home network



Step.1. After powering on, press and hold the ON/OFF button for 5-7 seconds, and the indicator light flashes quickly



(1)Tap"+" button on top right corner to add device.

6



Step.2 Enter Wi-Fi password to join your network



Step.3 Next



Step.4
Device added
successfully you can
modify device name.



Step D: Give a name to the switch and tap"Completed". you will find the device you've named is shown on the app home page. Tap the device to enter the setting page.



After completing Part Two. you can now control the switch with MySmartH APP on this setting page.

8

