

Set Administrator Password

Awake the lock pad



press "1"+"#" "



Enter the specified password and press "#" to confirm.

For example, enter "181818" and press "#"
(Password is 6 ~ 12 digits).



and press "#" to confirm



Add Cards

Awake the lock pad



press "2"+"#" "



Enter the administrator password



and press "#"



Place the card in the sensing area, and the system will prompt "Operation succeeded".



Add Fingerprints

Awake the lock pad



press "3"+"#"



Enter the administrator password



and press "#"



The system will prompt "Please press your finger",
Enter the fingerprint according to the system prompt, and the system will
prompt "Operation succeeded" after completion.



Install Free App

Download APP: scan the QR code below to download and install. Register and login: open the "MySmarth" APP to register and login according to the prompts.



Configure Network

Awake the lock pad



press "4"+"#"



Enter the administrator password



and press "#"





The system will prompt "Configure network".



Make sure Wi-Fi is available and connected to the Internet.

-Open "MySmarth" APP, press the '+' in the upper right corner of the main screen;

-choose "Home Safety", click "Smart Lock" to add Lock; and then click "Next step";






-If the mobile phone is not connected to wi-fi, please click "Connect to Wi-fi" ;



-It will jump to the WLAN interface and connects Wi-Fi. Please note that only 2.4 GHz Wi-Fi network is supported;

-Enter WIFI password

-When the progress reaches 100%, connection completed, and click "Done";



At this time, the connected device will appear on the APP home page . Then you can click directly to the device interface



Remote unlock mode

Awake the lock pad





Press **"#"** on the lock pad 2 Times



The App will ask for your confirmation to open remote



Click **"CONFIRM"** to unlock



Remote unlock mode (Dynamic Password)

Click phone screen and you will
get dynamic password




The password is automatically
saved in the clipboard, directly
copied and sent to the other
party's mobile phone



Awake the lock pad



Enter the dynamic password
and **#** key to unlock



Remote unlock mode (Temporary Password)

Click on the left bottom to set
Temporary password



Click **"Add"**







Set your own Temporary
password, name of user, and
the start and dead time.



Awake the lock pad



Enter the temporary
password and **#** key to
unlock



Restore Factory Settings



- 1.1. Remove the battery cover on the rear lock surface, and press the "Reset" button for 3 seconds until the voice prompts "System initialization, please press the confirm button".
- 1.2. Release the button and press the "#" key in the password input area to confirm.
- 1.3. The voice prompts "Operation succeeded", and all data of the system is cleared. The administrator password is restored to "123456".
- Warning: After restoring the factory settings, the smart lock added through the mobile APP can no longer be managed and configured by the mobile APP, please use it with caution!