

PIR

Product instruction manual



Packing List

- PIRx 1
- Reset needle x 1
- Battery x 1
- Instruction manual x 1

Please read the instruction manual carefully before using the product


Items Not Under Warranty

1. Unauthorized repairs, misuse, collisions, negligence, abuse, exposure of the product to moisture or water, accidents, alterations, improper use of accessories, tearing or alteration of stickers or anti-counterfeiting marks;
2. The validity period of the warranty has passed.
3. Damage caused by force majeure;
4. Damage or malfunction caused by problems other than the design, technology, manufacturing, quality of the product.

Product specifications

Product name	PIR
Battery specifications	AAA1.5V x 3
Detection distance	7 meters
Detection angle	170 degrees
Operating temperature	-10°C - 45°C
Operating humidity	10%-90% RH (no condensation)
Wireless connection	ZigBee


- Press and hold the reset button for 5 seconds, until the network indicator light begins flashing. Follow the App instructions to add the device.



- Once the device has been successfully added, you will be able to find the device in the "My home" list.

Product description

The human motion sensor uses infrared sensing to detect the movement of people or animals in the environment, and works in conjunction with other devices to design and implement smart application scenarios.



Preparation For Use

- 1 Mobile phone is connected to Wi-Fi



Ensure that the product is within the effective coverage of the smart host (gateway) ZigBee network to ensure an effective connection between the product and the smart host (gateway) ZigBee network.

*Make sure the smart host has been added.

Preparation For Use

- 2 Download and open the App


In the App Store or Google Play, search for " My SmarH "

If you are downloading this App for the first time, please tap the "Register" button to register your account; If you already have an account, click the "Login" button.



Network settings

- Connect the device to the power source while ensuring that the phone is connected to the network and the smart gateway has been added successfully;
- Open the App and tap "Add sub-device" on the "Smart gateway" screen. Then, select "PIR";



Amazon Echo Plus / Echo Show 2nd Gen

Using the reset needle, press and hold the reset button for 5 seconds until the indicator starts flashing red on the sensor.

Method 1: Ask Alexa to "Discover new devices"

Method 2: Add the sensor manually via Amazon Alexa app as displayed on the next page

New door sensor should now appear under Smart Home devices section and be ready for Alexa smart routines

Make Your Home Smarter