

Window Components



Satin Chrome

Chrome

Gold

White

Black

Maintaintance

- Carry out routine maintenance on your windows at least twice a year. In areas of high exposure, you may want to do this more frequently.
- All parts of your window that are exposed when closed should be washed down with warm soapy water using a soft cloth, then dried thoroughly.
- Any parts that are exposed when the windows are open, should simply be wiped clean, removing any grime, dirt, insect remains or old lubricant.
- You must avoid any cleaning agents that have ammonia in them or that are abrasive.
- Special attention should be paid to keep drainage channels clear and free from any blockages.







Locking & Unlocking

The Sash lock is used for locking and unlocking your vertical sliding window (see below). please note when unlocking your window you will need to remove the keys from the lock to engage/move the cam lock arm.





Use key supplied to lock or unlock Sash Lock

Opening



Remove keys when unlocked and rotate arm to unlock window (OPEN POSITION)

Closing/Locking



Rotate arm to lock window (CLOSED POSITION) Insert keys and lock (if required)



IMPORTANT: Please ensure that the keep and cam lock are parallel with each other before engaging the arm into the closed position.





Sliding

ECOSIIde PVC-U sash windows function like a wooden box sash window with both the top and bottom sashes sliding up and down to suit your ventilation requirements.

Convenient and simple to operate, the two sliding sashes within an outer frame work independently of each other on a balanced load mechanism, designed to hold the sash at any height.





Ventilation

ECOSlide windows offer improved circulation when both top and bottom sashes are open; when cool air comes in, warm air is pushed out.

IMPORTANT: Do not leave your windows in the tilted position for ventilation.







Tilt & Easy Clean

ECOSlide PVC-U sash windows are incredibly low maintenance, requiring only a quick wipe down with a damp cloth to keep them looking as good as new.

The window sashes feature an inward opening tilt facility to allow easy and safe cleaning of the outside frame and glass from inside your home. This is particularly useful for second storey windows or windows positioned in a hard to reach place, such as above a conservatory.





Tilting

To tilt windows, unlock cam lock to the open position, slide bottom sash/window up approx 50mm and then push tilt knobs in as shown on image and tilt window towards you (from the inside) to close window push the window to upright position and then push window down.

Please ensure both snap latches are located back into channel (see image below) or you may have issues closing/locking sash lock.





Travel Restrictors

These provide enhanced security and safety for your vertical sliding sash windows. They restrict the opening of the window to just 100mm.

To engage restrictors you will find a special restrictor key supplied with your window keys. Do not use other items for this, to prevent damage to the cam. Insert restrictor key into the black cam (as shown) and turn in a clockwise direction to make restrictor open out, to disengage restrictor push restrictor back into frame and turn cam anti clockwise using key provided.



Fit key into cam and turn clockwise to open restrictor



IMPORTANT: Only use the restrictor key provided to prevent damage to the restrictor cam



Push restrictor in and turn cam anti clockwise to close/lock restrictor

Energy Efficiency & Ratings

Enjoy a warmer, more comfortable

home with energy efficient sash windows

Windows are given energy ratings based on their ability to insulate your home. These are displayed on a colour scale ranging from 'A++' to 'E', with 'E' being the least energy efficient and 'A++' the most energy efficient.



Please note the information contained within this

are possible in the imminent future. Please check the relevant official websit

ECOSlide are not accountable for any errors or misleading information printed within this guide

Putting the style back into your home with **ECOSlide** will make your home a warmer and more comfortable place to live, saving on your energy bills year on year.

ECOSIIde PVC-U sash windows are 'A' rated as standard.

www.ecoslide.co.uk





BFRC Energy Window

Optional upgrade 'A+' rated

