

Samsung Mailbox Greetings

To change No Answer Greeting

- **Press VM key**
- **Enter password of the mailbox**
- **Press 5 to edit mailbox greetings**
- **Press 1 to edit no answer greeting**
- **Press 2 to record greeting**
- **Press # when finished**
- **Press 1 to set the greeting, you can now hang up.**

WWW.TAMPABAYTELEPHONE.COM