





Lista de precios de productos del IZZIBAN




[CEL/WhatsApp:5574905987 / 5579416772 / 5532306009 / 529987199999](https://www.whatsapp.com/business/catalog/5574905987)


imógen/图片	descripción/品名	pzas por caja/装箱数	barra de código /条码	código interno/货号	preció mayoreo/批发价格
	五星三角爱心冰格	144	6941840423410	423410	12
	梅花爱心冰格	144	6941840423427	423427	12
	正方形冰格	144	6941840403788	403788	12
	苹果切	144	6941840423434	423434	12
	L022单线切蛋器	144	6941840423441	423441	13
	L023切蛋器	144	6941840403993	403993	17
	666#4.5茶漏	144	6941840423465	423465	13
	776#4.5茶球	144	6941840423472	423472	13
	2PC黑色刷子	144	6941840402958	402958	14

	黑柄波浪纹	144	6941840423489	423489	12
	圆肉锤	144	6941840423496	423496	26
	方肉锤	144	6941840423502	423502	26
	016C搅拌器	144	6941840423519	423519	19
	砂罐转盖粉筒本色小号	144	6941840409315	409315	14
	砂罐转盖粉筒本色中号	144	6941840403603	403603	17
	砂罐转盖粉筒本色大号	144	6941840423526	423526	22
	鱼鳞刨	144	6941840406765	406765	10
	3PC冰铲	144	6941840423533	423533	13
	2PC冰激凌勺	144	6941840424530	424530	12
	5421#1000ML量杯PP	144	6941840423571	423571	14

	5422#500ML量杯PP	144	6941840423588	423588	13
	5423#250ML量杯PP	144	6941840423595	423595	11
	10寸沙拉勺	288	6973382312501	312501	10
	12寸沙拉勺	288	6973382312518	312518	11
	13寸沙拉勺	288	6973382312525	312525	11
	13寸搅拌勺	288	6973382312532	312532	11
	小切面刀	288	6941840423601	423601	8
	大切面刀	288	6941840423618	423618	10
	30*2.8cm自然平面杖	144	6973382318800	318800	14
	35*2.8cm自然平面杖	144	6941840402064	402064	15
	Φ8cm高边池漏	144	6973382316318	316318	12
	2PC大小池漏	144	6973382316301	316301	9
	3PC大中小网状池漏	144	6941840414227	414227	14

	2PC黑色大小水塞	144	6973382316295	316295	9
	小号白色池漏	144	6941840401531	401531	11
	大号白色池漏	144	6941840401548	401548	11
	方形烟灰缸	288	6941840415729	415729	6
	圆形烟灰缸	288	6941840415736	415736	6
	韩式双层烟缸	144	6941840415712	415712	15
	40*12单鱼	100	6941840423625	423625	31
	22.5*22.5二鱼	100	6941840423632	423632	32
	21.5*19.5小平板	100	6941840423649	423649	29
	21.5*19四汉堡	100	6941840423656	423656	31
	32*19扁柄六汉堡	100	6941840423663	423663	41
	6支小烧烤叉	144	6941840423687	423687	24

	3支大烧烤叉	144	6941840423694	423694	20
	6pc30方针	144	6941840423724	423724	15
	6pc35方针	144	6941840423731	423731	17
	6pc40方针	144	6941840423755	423755	20
	85pc0.3*20CM竹签	144	6941840423762	423762	9
	85pc0.3*30CM竹签	144	6941840423786	423786	10
	25pc0.9*40CM扁签	144	6941840418942	418942	13
	31cm加粗夹	144	6973382316349	316349	13
	36cm加粗夹	144	6973382314192	314192	14
	1寸羊毛刷	144	6941840423793	423793	10
	2寸羊毛刷	144	6941840423809	423809	12

	3寸羊毛刷	144	6941840423816	423816	15
	5.5寸牛扒刀	144	6941840438476	438476	14
	5寸牛扒叉	144	6941840438483	438483	14
	28.5cm 鱼铲	144	6973382312006	312006	49
	33.5cm 中圆头直铲	144	6973382312013	312013	25
	20.5cm 牛油刀	144	6973382312020	312020	19
	24.5cm 大Y型平铲	144	6973382312037	312037	28
	26.5cm 蛋糕铲	144	6973382312044	312044	24
	22.5cm U型刨	144	6973382312051	312051	27
	27cm 打蛋器	144	6973382312068	312068	25
	20cm 果心抽	144	6973382312075	312075	24
	15cm 果子勺	144	6973382312082	312082	23




	18.5cm 尖头汽水抽	144	6973382312105	312105	24
	16cm 双托碌	144	6973382312112	312112	26
	□7.5cm中介饼轮	144	6973382312129	312129	28
	18cm 雪糕更	144	6973382312136	312136	26
	18.5cm 鱼鳞刨	144	6973382312143	312143	20
	20.5cm 芝士铲	144	6973382312150	312150	27
	32cm 小意粉捞	144	6973382312167	312167	38
	30.5cm 肉汁密更	144	6973382312174	312174	38
	33.5cm 平密铲	144	6973382312181	312181	38
	33.5cm 平漏铲	144	6973382312198	312198	38
	29.5cm 汤勺	144	6973382312204	312204	41
	30cm 条形捞篱	144	6973382312211	312211	41
	32cm 时尚饭勺绑卡	144	6973382312235	312235	35


	31.5cm 时尚汤勺绑卡	144	6973382312259	312259	35
	32cm 时尚平铲绑卡	144	6973382312266	312266	35
	时尚油刷绑卡	144	6973382312273	312273	35
	32cm 时尚漏铲绑卡	144	6973382312280	312280	35
	E003A面包刀绑卡	144	6973382312297	312297	31
	E001A厨师刀绑卡	144	6973382312303	312303	35
	E002A切肉刀绑卡	144	6973382312310	312310	31
	E005A果皮刀绑卡	144	6973382312327	312327	17
	E004A万用刀绑卡	144	6973382312334	312334	18
	3号强力剪绑卡	144	6973382312358	312358	18
	无拆厨房剪绑卡	144	6973382312372	312372	26
	30cm方形冰格套卡	144	6973382312389	312389	18

	两用扫仔刨	144	6973382312419	312419	19
	□10cm 塑柄捞喱绑卡	144	6973382312433	312433	24
	12cm塑柄塑网漏	144	6973382312471	312471	14
	8358-S2 六面刨套卡	72	6973382312549	312549	32
	8268-S2 8寸四面刨	72	6973382312556	312556	26
	223冰铲	144	6973382312587	312587	15
	双头量杯量匙	144	6973382312594	312594	22
	220塑冰铲	72	6973382312600	312600	15
	462沥水勺	144	6973382312617	312617	15
	20.6cm多用榨汁器	144	6973382312655	312655	33
	4pc便携菜板套卡	24	6973382312686	312686	78
	29cm 平板蔬菜刨	144	6973382312693	312693	28

	22.5cm 5孔开罐器	144	6973382312709	312709	22
	双层榨汁杯环卡	72	6973382312723	312723	21
	492 2pc塑料夹	72	6973382312730	312730	18
	YE007-2 2pc瓶塞吸卡	144	6973382312747	312747	20
	6pc两用倒酒器吸卡	144	6973382312754	312754	15
	3pc新倒酒器吸卡	144	6973382312761	312761	13
	10cm塑酒塞绑卡	288	6973382312778	312778	11
	1349切蛋器吸卡	144	6973382312785	312785	37
	蛋清分离器吸卡	144	6973382312792	312792	15
	□7 披萨刀	144	6973382312815	312815	32
	V010T 12寸梅花食品夹	144	6973382312839	312839	42
	12"小烹饪打蛋器7线	144	6973382312846	312846	18
	ABS塑料粉筛单层	72	6973382312860	312860	54

	3pc 量碗	24	6973382312877	312877	68
	500ML pc量杯	48	6973382312891	312891	30
	5pc 量杯绑卡	144	6973382312938	312938	14
	6pc 量勺绑卡	144	6973382312945	312945	10
	426 量勺6pc	144	6973382312952	312952	23
	花型饺子模插卡	72	6973382312976	312976	19
	心形饼干模插卡	72	6973382312983	312983	19
	25cm圆柄中号油刮绑卡	144	6973382312990	312990	19
	24cm圆柄中号牛油刀工绑卡	144	6973382313010	313010	18
	23.5cm圆柄115柱扫绑卡	144	6973382313027	313027	19
	小号圆形折叠沥水蔬菜篮	72	6973382313072	313072	27
	27.5cm 防滑蛋糕转盘	24	6973382317001	317001	58
	抹刀吸卡	144	6973382317018	317018	20
	8010 3pc刮刀	144	6973382317032	317032	22
	228 9pc奶油笔双卡泡	144	6973382317049	317049	28

	连接器A插卡	144	6973382317056	317056	10
	双色裱花袋10片	144	6973382317063	317063	15
	单色裱花袋20片	144	6973382317070	317070	15
	6pc奶油袋吸卡	144	6973382317087	317087	13
	8嘴挤奶器吸卡	144	6973382317094	317094	13
	1831 7嘴奶油裱花袋	72	6973382317100	317100	26
	8015 6嘴加袋裱花器	144	6973382317117	317117	21
	1832 7嘴奶油裱花袋	48	6973382317124	317124	42
	4138 8嘴挤奶器	72	6973382317131	317131	23
	6pc 裱花器吸卡	72	6973382317148	317148	31
	双色裱花组合双泡	48	6973382317155	317155	32
	单色裱花组合双泡	48	6973382317162	317162	32
	2pc 姜饼人塑饼模吸卡	144	6973382317209	317209	18
	5pc 爱心波浪饼模绑卡	144	6973382317216	317216	19
	5pc 圆形波浪饼模绑卡	144	6973382317223	317223	19

	5pc 雪花波浪饼模绑卡	144	6973382317230	317230	19
	3pc高花边饼模吸卡	144	6973382317247	317247	19
	圆形慕斯圈吸卡	144	6973382317254	317254	16
	爱心慕斯圈吸卡	144	6973382317261	317261	16
	梅花慕斯圈吸卡	144	6973382317278	317278	16
	三角慕斯圈吸卡	144	6973382317285	317285	16
	分层可伸缩蛋糕模	24	6973382317292	317292	52
	圆形刻度可伸缩蛋糕模	24	6973382317308	317308	52
	10pc 数字蛋糕模	144	6973382317315	317315	33
	013-4裱花模	144	6973382317322	317322	16
	011-3裱花模	144	6973382317339	317339	17
	6pc 小号裱花嘴	144	6973382317346	317346	16
	9pc 小号裱花嘴	144	6973382317353	317353	21
	6pc大号裱花嘴	144	6973382317360	317360	23