

Basic Formula First Chassis Settings: **Hoosier Recomendations**

Beam Caster (measured across the upper and lower tubes): 1 to 2 degrees max (top tube tipped back)

Note: Always set the caster/camber eccentrics to minimize caster with correct camber set. Caster/camber eccentrics should be adjusted prior to setting toe

Front Camber: $\frac{3}{4}^{\circ}$ negative each side

Front Toe: $\frac{1}{8}$ " to $\frac{3}{32}$ " out

Rear Camber: $\frac{1}{2}^{\circ}$ to $\frac{3}{4}^{\circ}$ negative each side

Rear Droop: Max. 3° positive camber (total)

Rear Toe: Zero to $\frac{1}{32}$ " in

Tire Pressure Range (Hoosier R60A):

Front: 12 to 13 psi cold

Rear: 14 to 15 psi cold

July 22, 2008