

CATCH THE LIGHT COMBO PARTS



Player Button (Red / Blue)
Part Number: CTL001



Start Button
Part Number: CTL002



Button Switch
Part Number: CTL003




Button LED Bulb
Part Number: CTL004



Power Source (75W)
Part Number: CTL005-A



Power Source (80W)
Part Number: CTL025-B



Button Wiring (one side
left/ right)
Part Number: CTL007




Score Display
Part Number: CTL008



Time Display Set
Part Number: CTL009



Locks Set (1 x Money Box
2x Top Frame)
Part Number: CTL010



Plastic Corner Cover
(Large, Bottom)
Part Number: CTL013



Plastic Corner Cover
(Small, Top)
Part Number: CTL014



Coin Acceptor
(Electronic, Taiwan)
Part Number: CTL015




Bill Acceptor (BV20)
Part Number: CTL017



Ticket Dispenser
Part Number: CTL018



Ticket Box
Part Number: CTL020



Main Board
Part Number: CTL021



SD Card
Part Number: CTL022



RGB LED Driver
Part Number: CTL023



Speaker
Part Number: CTL024