



## FC-016 Flower Bee



### Specification

**Dimension** L130 x W85 x H125 cm


**Weight** 80 kgs

**Voltage** 110V AC, 60Hz, 3A, Max 6A  
220V AC, 50Hz, 3A, Max 6A

---

[www.barrongames.com](http://www.barrongames.com)

**Flower Bee Detail Manual**





- 1. Light#2
- 2. Electronic coin machine(key#1)
- 3. Maintenance door-big(key#1)
- 4. Double frame
- 5. Music box
- 6. Controller
- 7. Coin box(key#2)
- 8. Power-plug locates at rear of base
- 9. Fixer

- 10. Wheel
- 11. Central carousel
- 12. Flower FRP
- 13. Bee FRP
- 14. Steering wheel#1


s1~s2. Sticker

**Double Frame Wire Manual**



size: W188mm x L78mm x H113mm

**Controller Operating Manual**



**Count:** Adjust the coin from 1 coin to 5 coins

**Stop Button:** For Checking machine without insert coin to "STOP" the machine

**Start Button:** For Checking machine without insert coin to "START" the machine

**Reset:** Red lighting when power connect


**Start:** Green lighting when machine start to working

**1~12 play Time adjust:**

- |                             |                             |
|-----------------------------|-----------------------------|
| 1. 1 Minute and 30 Seconds  | 7. 3 Minutes and 30 Seconds |
| 2. 1 Minute and 40 Seconds  | 8. 4 Minutes                |
| 3. 1 Minute and 50 Seconds  | 9. 4 Minutes and 30 Seconds |
| 4. 2 Minutes                | 10. 5 Minutes               |
| 5. 2 Minutes and 30 Seconds | 11. 10 Seconds for testing  |
| 6. 3 Minutes                | 12. 0                       |



**Music Box Operating Manual**



- 1. **1-12:** Sound volumes adjust
- 2. **Sound button connection**
- 3. **Power light:** When power connect
- 4. **Counter:** Coin Counter
- 5. **Music:** 12 English kiddy songs to repeat



front view





side view



back view

**Electronic Coin Machine Operating Manual**



size:mm

**Electronic Coin Machine Operating Manual**

**DIDGITAL COMPARABLE ELECTRONIC  
INSTALLATION HI-07CS+LED**

**STEP1**

Cheng the right coin for use from the clamp.

**STEP2**

Adjust the right insert size for use from the front panel back side.

**STEP3**

Select the right mode: Normal Open/ Normal Close\* **TIMER SWITCH\*** for synchronizing your system.

100ms (Slow Speed/ Long Pulse)

50ms (Medium Speed/ Medium Pulse)

30ms (Fast Speed/ Short Pulse)

**STEP4**

Adjust VR sensitivity tuning

Clockwise: slack selection (LED dark->light)

Anti-clockwise: strict selection (LED light->dark)

**STEP5**


Gray Line Counter (+/-)

Red Line DC+12V

White Line Coin Signal



Black LINE GND (Ground)

Gray Line Counter (+/-)




**Counter**

**STEP6**




**Coin Box Manual**




size: W175mm x L145mm x H175mm



**Maintenance Door-Big Manual**



size: W267mm x L20mm x H232mm





# **BARRON**

---

# **GAMES**

INTERNATIONAL

84 Aero Drive  
Suite 4  
Buffalo, New York, 14225, USA

Phone: **1 (716) 866-0054**

Fax: 1 (716) 630-0055

E-mail: [info@barrongames.com](mailto:info@barrongames.com)

Visit: [www.barrongames.com](http://www.barrongames.com)

