



## Banner Care

Matte Vinyl | Gloss Vinyl

### Care and Cleaning instructions

*Congratulations on your purchase of a quality product!*

Please bear in mind that gloss or matte vinyl banners exposed to environmental and weather stress can be damaged. For outdoor display, use the grommet openings and tightly secure your banner to prevent wind action. All banners, especially mesh vinyl, can be quickly damaged by wind. Exposure to direct sunlight should be avoided when possible. In order to enjoy your product for an extended period of time, you should observe the following instructions regarding treatment and cleaning.

#### Treatment

- Retain the shipping carton for future storage.
- For storage, roll your banner with the image facing outward and replace in shipping carton.
- **NEVER** fold or crease your banner.
- **NEVER** allow the ink surfaces to touch.
- **NEVER** place tape or adhesives on the ink surface. Adhesive materials and ink will cause irreparable damage.
- Banners must hang freely so that they do not come into contact with trees, wires, masts or · The quality and life span of banners can be dramatically decreased from long-term exposure to direct sunlight.

#### Cleaning and washing

- For most small spots, we recommend cleaning by hand with mild soap and water. Rub gently in a small circular motion around the soiled area. Avoid aggressive scrubbing. After cleaning, wash thoroughly, and allow drying.
- Vinyl banners can also be safely cleaned with ammonia-free window cleaners.

#### Bleach and other cleaning products

**NEVER** use bleach, solvents or other caustic agents for cleaning. These will cause irreparable damage to your banner.

#### CONTACT INFORMATION

**BannersforChurches.com | PO Box 1224 | Brentwood, Tennessee 37024  
customerservice@bannersforchurches.com | 615.395.8024**