



Banner Care

Fabric Banner Products

Care and cleaning instructions

Congratulations on your purchase of a quality product!

Please bear in mind all fabric banners exposed to environmental and weather stress can be damaged. In order to enjoy your product for an extended period of time, you should observe the following instructions regarding treatment and cleaning.

Treatment

- Banners must hang freely so that they do not come into contact with trees, wires, masts or buildings. During inclement weather and at night, banners should be moved indoors.
- The quality and life span of banners can be dramatically decreased from long-term exposure to direct sunlight.
- For optimum banner life, we recommend fabric banners be displayed in a predominantly climate-controlled environment.

Washing, drying, ironing

- For most small spots, we recommend cleaning by hand with mild soap and water. Rub gently in a small circular motion around the soiled area. Then wash thoroughly, and hung wet to dry.
- Branded polyester banners can be washed in all household washing machines at 140°F (60°C) with the addition of washing detergent.
- Following washing, banners should be rinsed thoroughly.
- For drying, banners should be hung wet.
- If your banner has wrinkles, we recommend steaming, then hang and allow to fully dry. Products for interior decoration can be ironed in accordance with the prescribed care symbols. Please use low heat setting.

Dry cleaning

As a fundamental rule, **dry cleaning is not recommended** for our fabric banners. Solvents used in dry cleaning can damage your banner. No guarantee can be given for the color fastness of banners subjected to this process.

CONTACT INFORMATION

**BannersforChurches.com | PO Box 1224 | Brentwood, Tennessee 37024
customerservice@bannersforchurches.com | 615.395.8024**