








COMPONENTS


A	FRONT GROUND ANCHOR	x11	
B	GROUND PEG	x11	
C	TENSION PEG with attached NYLON CORD	x4	
D	LARGE QUICK RELEASE BUTTON	x11	
E	ARROW HEAD NET FIXING with attached LOCKING PIN	x22	
F	RESPECT BARRIER POST	x11	
F	POST CAP	x11	

CHN CHAIN LINK
25 Metres


x2 

50m RESPECT BARRIER - CHAIN LINK WITH PLASTIC ANCHOR

Post sizes available
815mm or 580mm LONG -




OPTIONAL METAL ANCHORS
Metal anchors can be added to the system for extra strength and stability, useful on long lengths of barrier



DO NOT THROW THE LOCKING PINS AWAY




WARNING




DO NOT LEAN ON POSTS OR CHAIN.


RESPECT BARRIER POSTS WILL NOT BE REPLACED WITHIN THE GUARANTEE PERIOD IF MISUSED. THE RESPECT BARRIER IS ONLY A SEPARATOR BETWEEN SPECTATORS AND PLAYERS.




FRONT GROUND ANCHORS HAMMER FULL DOWN INTO THE GROUND




1. Make sure the front Ground Anchor is inserted fully and level with the grass surface. If the ground anchor is not fully inserted when pegged down, tension will cause the peg slot to break.



1. With your first barrier post in position use the tension peg to reinforce stability before assembling the rest of the barrier pack. Always start erecting the barrier from one side for an easy and efficient assembly (steps 1 - 2).



1. Attach your first chain link onto the arrowhead fitting. You will need approximately 5 metres of chain link per post distance (steps 3 - 4).



1. On the last barrier post use a tension peg to complete your barrier system and reinforce stability. **To dismantle** simply start at one end and follow the steps in reverse order un-pegging and un-linking the posts (steps 5 - 6).

Please note: This is a temporary quick-fit barrier to separate spectators from players for a more permanent solution please visit itsagoal.co.uk