




**SPARE PARTS** TEL: 0114 24 24 244





## FRONT GROUND ANCHORS HAMMER FULL DOWN INTO THE GROUND





Post sizes available 815mm or 580mm LONG

**OPTIONAL METAL ANCHORS** 

useful on long lengths of barrier

Metal anchors can be added to the

system for extra strength and stability,

1. Make sure the front Ground Anchor is inserted fully and level with the grass surface. If the ground anchor is not fully inserted when pegged down, tension will cause the peg slot to break.

MALLET

WOOD

BLOCK

When the Ground Anchor is in position you can now slide the Uprights onto the anchors.


To secure the Anchor in the ground use a Ground peg which will keep the Anchor in place.

The Front Ground Anchors need to be sunk into the ground. For hard grass surfaces You may need to hammer the Front Ground Anchor. Use a wood block to protect the Anchor

WARNING: ALWAYS WATER THE GROUND TO SOFTEN BEFORE HAMMERING THE



RESPECT BARRIER POSTS WILL NOT BE REPLACED WITHIN THE GUARANTEE PERIOD IF MISUSED. THE RESPECT BARRIER IS ONLY A SEPARATOR BETWEEN SPECTATORS AND PLAYERS.




NYLON **ANCHOR** 

METAL **ANCHOR** 

Pre drilled holes


ready to take optional nylon rope




Tether ends of the

posts for extra stanbility

rest of the barrier pack. Always start erecting the barrier from one side for an easy and efficient assembly



1. Attach your own rope into pre drilled holes. You will need approximately 5 metres of rope between



1. On the last barrier post use a tension peg to complete your barrier system and reinforce stability. To dismantle simply start at one end and follow the steps in reverse order un-peging and un-linking the posts (steps 5 - 6).

Please note: This is a temporary no load bearing quick-fit barrier to separate spectators from players for a more permanent solution please visit itsagoal.co.uk

