



**\*\*\*REMINDERS TO SAVE YOU MONEY\*\*\*:**

- **All equipment, tools, machinery, and attachments must be cleaned and re-fueled prior to return or shall be subject to a minimum \$250 cleaning fee per item, fuel at a rate of \$10/gal, and DEF at a rate of \$12/gal.**
- **NO SMOKING in machines** – any evidence of such will result in a \$500 smoking fee IN ADDITION TO the above \$250 cleaning fee if the machine (including tracks, wheels, glass, paint, cab, etc.) itself is dirty, muddy, greasy, dusty, has garbage left behind, or is in any way unclean.
- **OVERUSAGE:** 1 Day Rental = 7am-5pm, no more than 10 machine hours; 1 week rental = 7am on the day out through 5pm on the 7th day, no more than 50 machine hours; 1 month rental = 7am on the day out through 5pm on the 28<sup>th</sup> day, no more than 250 machine hours; *any hours over these limits will be charged at a rate of \$100 per machine hour, rounded up to the nearest whole hour.*
- **NO SUBLEASING** – All equipment rented is intended solely to be rented and operated only by the customer listed; any attempt to sublease any machinery or equipment will be deferred to our attorney for breach of contract. Criminal charges may apply.
- **Machinery and Equipment is NOT TO BE MOVED TO ANY OTHER LOCATION aside from the premises address agreed upon unless approved, in writing, by KB Equipment Rental, LLC.** Per your contract, steep fines apply for doing so and criminal charges may apply.
- **\*Please allow machine to warm up for 10 minutes prior to use if the outside temp is below 50 degrees F.**
- **\*PLEASE TURN THROTTLE DOWN AND LOWER BUCKET/BOOM ONTO THE GROUND BEFORE TURNING OFF THE MACHINE TO KEEP WEIGHT OFF OF THE HYDRAULICS WHEN NOT IN USE.**
- *Please follow manufacturer's instructions for safe operation and intended use. Please always use proper protective equipment when operating any equipment. Customer assumes all liability associated with the use or operation of the above items and holds harmless KB Equipment Rental, LLC (dba KB Equipment Rental), its owners, members, employees, mechanics, affiliates, suppliers, contractors, subcontractors, partners, and associates.*

**THANK YOU FOR SUPPORTING LOCAL. A PORTION OF OUR PROCEEDS BENEFIT LOCAL VETERANS AND FIRST RESPONDERS.**

***PLEASE leave us a review on Facebook or Google if you feel we've done a great job! This helps small businesses such as ours get seen and stay seen. It would mean the world to us (Pretty Please)!***

**We truly aim to please, but we recognize things may not always be perfect. If you are in ANY WAY unsatisfied, please reach out to us so we can make it right BEFORE resorting to leaving a poor review. This kills small businesses unfairly. We can't help you if we aren't aware and we promise we care, so please let us know. We have been thankful to be supported by such an incredible community. We sincerely appreciate you.**

**\*\* BREAKDOWNS\*\*:**

Please both **TEXT** and **CALL** our main line, 724-698-2700 as well as **TEXT** and **CALL** our maintenance tech, Brandan Reesman of MBR Repair, at 724-525-0498. Leave a voicemail if you get the voicemail greeting.

A "HOW TO" video is under the "HOW TO" tab on our website, [www.rentKB.com](http://www.rentKB.com), to show you how to operate the machine.

**"REGEN" Light** (*Don't Panic, it's Normal every 20h or so, Keep Running Machine per usual with throttle above 50% until the light disappears – sometimes takes a few hours*)



*\*This document is provided solely as a quick reference guide for informational purposes. Any user of this document must independently verify its suitability and applicability to account for the user's specific workplace environment, practices, and legal requirements. Please refer to the Operator's Manual for how to operate the equipment. The user assumes all risks and liabilities with respect to the use of this document.*

## **\*\*\*QUICK START GUIDE: KUBOTA SVL-75\*\*\*:**

1. Put Seatbelt On
2. Start the Machine by Turning the Key to the Right, let run for 10 mins



Fuel Gauge/Hour Meter


1. Toggle the "AUX" button to engage **hydraulic thumb** – THEN, the thumb is controlled by the button on the right joystick



1. KEY/IGNITION
2. Safety (Lock)
3. Parking Brake
4. Auxiliary
5. Headlights/Rear Lights (Flip Once for Headlights and Twice for Headlights AND Rear Lights)

3. Flip the **Safety Harness Down** on Your Left and Your Right to Your Lap (Circled in Yellow in Photo on the Right) **AND** push the green "**Safety**" button on your right to Unlock and Engage the Machine; if the "**Parking Brake**" is also engaged, you'll need to release it on the red button on the right before the machine will engage.

- o Move the Entire Machine Forward or Backward or Turn Left/Right with the **Left Joystick**
- o Control the Bucket/Boom with the **Right Joystick**:
  - Lift Bucket/Boom Vertically by pushing Joystick Forward/Backward
  - Curl the Bucket Inward/Outward by pushing Joystick Left/Right
  - **Attachments**:
    - If you have attachments that require auxiliary items, such as an auger, please ensure the "**AUX**" button is engaged on your right THEN utilize the "thumb" button on top of the right joystick to engage your attachment
    - Use the "**Quick Attach**" button on your left (flip up cover to reveal button) to remove/add an attachment – lower the attachment on the ground first!
- o Use the "**Hand Throttle**" circled below OR the "Foot Pedal" throttle to control speed
- o **\*\*\*DO NOT push the "REGEN" button on your left – Doing so could clog the DPF and cause the engine to lose power, requiring us to fix it; in this event, you will NOT be refunded and you will be responsible for the cost to repair.**



QUICK ATTACH



RIGHT JOYSTICK & THUMB



HAND THROTTLE

FOOT PEDAL (THROTTLE)



REGEN (DO NOT TOUCH!)

**PLEASE LOWER THROTTLE AND LOWER BUCKET/BOOM ONTO THE GROUND BEFORE TURNING OFF THE MACHINE TO KEEP WEIGHT OFF OF THE HYDRAULICS WHEN NOT IN USE.**