

SUPPRESSOR- USE AND CARE INSTRUCTIONS

INSTALLATION-

Firearm must be unloaded before installation.

Ensure muzzle threads are clean and undamaged.

Thread suppressor onto muzzle, ensuring it is firmly seated against the shoulder.

It is recommended to check bore alignment with an alignment rod.

If suppressor loosens after shooting, it will need to be retightened.

If rapid fire shooting, torquing the suppressor with a wrench is recommended.

REMOVAL-

Allow to cool before attempting to remove device.

Unthread device by hand, or using a wrench.

DISASSEMBLY-

Remove end cap using included wrench.

Baffles can be pushed out using a dowel, if they do not fall out.

ASSEMBLY-

Insert all baffles with small end in, and large end out.

Spin all baffles, once installed, until they all lock together, and lock into the housing(disregard this step for poquito model, as it has no indexing keys)

Ensure 3/8" depth from end of housing to end of final baffle, before installing end cap.

Apply anti- seize lubricant to end cap threads before threading into housing.

Torque end cap into housing using included wrench.