

Obtuse Angle → Miter Saw Setting Chart

How to use:

1. Measure the inside corner angle with your digital angle finder.
 2. Find your measured angle in the left column.
 3. Set your miter saw to the matching setting in the right column.
- This chart is for obtuse angles (over 90°).

Measured Corner Angle	Miter Saw Setting
91°	44.5°
92°	44.0°
93°	43.5°
94°	43.0°
95°	42.5°
96°	42.0°
97°	41.5°
98°	41.0°
99°	40.5°
100°	40.0°
101°	39.5°
102°	39.0°
103°	38.5°
104°	38.0°
105°	37.5°
106°	37.0°
107°	36.5°
108°	36.0°
109°	35.5°
110°	35.0°
111°	34.5°
112°	34.0°
113°	33.5°
114°	33.0°
115°	32.5°
116°	32.0°

117°	31.5°
118°	31.0°
119°	30.5°
120°	30.0°
121°	29.5°
122°	29.0°
123°	28.5°
124°	28.0°
125°	27.5°
126°	27.0°
127°	26.5°
128°	26.0°
129°	25.5°
130°	25.0°
131°	24.5°
132°	24.0°
133°	23.5°
134°	23.0°
135°	22.5°
136°	22.0°
137°	21.5°
138°	21.0°
139°	20.5°
140°	20.0°
141°	19.5°
142°	19.0°
143°	18.5°
144°	18.0°
145°	17.5°
146°	17.0°
147°	16.5°
148°	16.0°
149°	15.5°
150°	15.0°