

## 1 Year Limited Warranty

Watches are warranted by Bradstreet & Mohr™ against manufacturing and material defects and/or improper functioning for a period of one year from date of purchase. In the case of timekeeping accuracy, a variance of within +/- 45 seconds per day for mechanical watches when properly wound, and +/- 30 seconds per month for battery-powered watches is considered within normal range.

Defective watches will be repaired or replaced at our option, and this will not extend the original 1 year warranty. Watches must be accompanied by dated proof-of-purchase and returned only to our designated USA facilities at buyer expense. We have no responsibility for reimbursement of service performed by others. We do not assume any responsibility for packages lost, stolen or damaged during shipping to our facilities. So, we recommend carefully packaging and returning watches via trackable, insured shipping.

Crystals, straps, batteries and plated finishes are not covered. Watches damaged by accident, abuse, improper operation, unauthorized repair, alteration, or normal wear and tear are excluded. Watches damaged by water incursion from customer misuse shall void the warranty. (IE: Failure to secure the crown before water submersion, operation of pushers while submerged, or exceeding the dive rating.)

## Use and Care of Watch

1. Watches of 30 Meters or less or unmarked are of a minimal water resistance rating that is splash and rain resistant. Diving, swimming or showering requires a 50 Meter or greater rating. Make sure that the crown is fully pushed in or screwed down to maintain water resistance. Do not operate the crown or pushers while submerged under water.
2. The internal mechanism of the watch is delicate and sensitive to shocks and magnetic fields.
3. The crystal is fragile. Take care to avoid knocks or dropping the watch.
4. Avoid extreme heat, cold and close proximity to magnetic fields. Keep away from electric and electronic devices, especially electric motors and speakers.
5. Avoid corrosive chemicals. Clean with mild soap and rinse with water, especially after sea water immersion.
6. Failure to follow these precautions may void your warranty.

©2022 Bradstreet & Mohr. All rights reserved.


# BRADSTREET & MOHR™

## Instructions & Warranty

**Bradstreet & Mohr Watches**  
4533 MacArthur Bl., Ste A5055  
Newport Beach, CA 92660  
USA

website: [www.bradstreet-mohr.com](http://www.bradstreet-mohr.com)  
e-mail: [info@bradstreet-mohr.com](mailto:info@bradstreet-mohr.com)

## Setting Instructions



### Position 1: (Default)

Manual wind Crown 15 turns to start watch. (Mechanical watches only.)

**Position 2:** Pull Crown out and Rotate to set Date, if equipped.

**Position 3:** Pull out & rotate to set hour and minutes hand. (second hand will be stopped-push in on time signal to start.)

**Dive watches:** If crown doesn't pull out, it is equipped with a screw-down crown, which must first be unlocked by turning counter-clockwise before crown can be in position 1. After winding and setting watch, push crown in fully while turning clockwise to lock it down to preserve water resistance.

## Maintenance and Service

Watches are tested and carefully checked before leaving the factory. With proper care, your mechanical watch should function for many years without the need for any maintenance. We recommend having your watch checked for servicing by a local professional watch service facility familiar with Japanese movements every 3 to 6 years depending on how often you wear your watch, or when you notice a change in performance. Battery powered watches will need a new battery every 1 to 3 years. Gaskets should be inspected and watches pressure tested periodically or when servicing to maintain water resistance.

**Note:** Automatic Mechanical watches are self-winding with arm motion and do not need manual winding if worn for 8 hours minimum everyday. If the watch is not worn for approximately 40 hours, it will stop running. In this case, hand wind the watch with 15 turns of the crown to start it running.

## Proof of Purchase

Model \_\_\_\_\_

Date of Purchase \_\_\_\_\_

Purchaser \_\_\_\_\_

Authorized Signature \_\_\_\_\_

### Save for your records

This completed Proof of Purchase must be submitted for warranty service.

**BRADSTREET  
& MOHR™**