

KITCHEN & BATH DESIGN

Finding Your Style



White Oak (PC)
Frameless



Frameless White (PB)
Frameless



Silver Oak (P1)
Frameless




Espresso Shaker (E)



Cherry Shaker (F)



Cherry Raised Panel (G)



High Gloss White (L)




Antique White (N)



Grey Shaker (R)



Snow White (V)



White Shaker (W)




Charcoal (X)



Chocolate Cherry (C)




Honey Oak (A)



Flat White (B)

WALL CABINETS




W1812
W2412/W2415/W2418/W2421
W2712/W2715/W2718/W2721
W3012/W3015/W3018/W3021
W3312/W3315/W3318/W3321
W3612/W3615/W3618/W3621
W3918

W2424/W2427
W2724/W2727
W3024/W3027
W3324/W3327
W3624/W3627

W930/W936/W940
W1230/W1236/W1240
W1530/W1536/W1540
W1830/W1836/W1840
W2130/W2136/W2140

W2430/W2436/W2440
W2730/W2736/W2740
W3030/W3036/W3040
W3330/W3336/W3340
W3630/W3636/W3640
W3930/W3936/W3940

W301224/W331224/W361224
W301524/W331524/W361524
W301824/W331824/W361824
W302124/W332124/W362124
W302424/W332424/W362424
W302224




MWC2430/MWC2436/MWC2440
MWC2730/MWC2736/MWC2740
MWC3030/MWC3036/MWC3040

MCS2418
MCS2718
MCS3018

WEOS630/WEOS636/WEOS640
WEOS930/WEOS936/WEOS940
WEOS1230/WEOS1236/WEOS1240

WDC2130/WDC2136/WDC2140
WDC2430/WDC2436/WDC2440
WDC2412

BASE CABINETS *(Frameless Cabinet: All base cabinets with one top single drawer only)*




B09/B12/B15
B18/B21

B24/B27/B30

B33/B36/B39

HB09/HB12/HB15
HB18/HB21

HB24/HB27/HB30
HB33/HB36/HB39



DB09/DB12/DB15/DB18
DB21/DB24/DB27/DB30
DB33/DB36


BSR09

SBA36/SBA39


BBC3036-9/BBC3339-12
BBC3642-15/BBC3945-18

CB33 (with shelf)
CB36 (with shelf)


BASE CABINETS *(Frameless Cabinet: All base cabinets with one top single drawer only)*




SB24
SB27
SB30




SB33
SB36
SB39



BWB18




BEOS0924
BEOS1224




ROT15/ROT18/ROT21
ROT24/ROT27/ROT30
ROT33/ROT36/ROT39


PANTRY CABINETS




W301224/W301824
W302224
&
OVD3072




WP153024/WP183024/WP213024
WP153624/WP183624/WP213624
WP154024/WP184024/WP214024
&
WP1554/WP1854/WP2154



WP243024/WP273024/WP303024
WP243624/WP273624/WP303624
WP244024/WP274024/WP304024
&
WP2454/WP2754/WP3054




WR3030GD/WR3036GD
WR3040GD




WR3015/WR3018


VANITY CABINETS *(Frameless Cabinet: All vanity with one top or bottom single drawer only)*




VSB24
VSB27
VSB30




VSB33
VSB36
VSB39




VD12-3/VD15-3
VD18-3/VD21-3




VD12-1/VD15-1
VD18-1/VD21-1



VD24-1




VSB24/VSB27/VSB30
VSB33/VSB36/VSB39




VSD36-3L/VSD36-3R


ACCESSORIES




Solid Filler
F2x30/F3x30
F2x40/F3x40/F4x40
F2x96/F3x96




Fluted Filler
FF3x30
FF3x40
FF3x96




Base End Panel (1/4" thickness)
BEP5mmx22.5



Base End Panel (5/8" thickness)
BEP15mmx25/DWP
BEP15mmx25-3/4




Wall End Panel (1/4" Thickness)
WEP5mmx10.5x30
WEP5mmx10.5x40



Wall End Panel (5/8" Thickness)
WEP15mmx13x31-1/2
WEP15mmx13x41-1/2




Post
FP3x34-1/2
FP5x34-1/2




Base End Door
BED24x30
BED25x30




Turntable
LS28(1SET)




Crown Moulding
CM8-F




Crown Moulding
CM8x2-1/2
CM8x3-3/4




Crown Moulding
CM8x4h




Light Moulding
LM8




Light Moulding
CLR8




Scriber Moulding
SM8-1"




Corner Moulding
OCM8-1"




Corbel
KC-L (5-1/2"w, 8-1/4"h, 4-5/8"d)
KD-M (3"w, 6"h, 3-1/4"d)
KD-S (3"w, 4-7/8"h, 1-7/8"d)




Toe Kick (1/4" Thickness)
TK8




4x8 Panel
PN48x96x15mm
PN48x96x5mm



Fridge Panel
PN24x96x18mm
PN25x96x18mm
PN30x96x18mm



Dentil Moulding
DM8 (96"w, 1-1/2" h, 1/4"d)



Base Moulding
BM8 (96"w, 4-1/2"h, 3/4"d)