

LBP

Low Battery Protector



LBP FUNCTION AUTO SAFE GUARD (LBP ON / OFF)

The dash cam itself can monitor your vehicle's battery voltage level.

You can change the feature from the dedicated GNET PC VIEWER or GNET APP.

If the voltage level is under the value you set, it will automatically be turned off and leave your car battery has some level of current.



SAFEGUARD

It is an intelligent SAFEGUARD function that automatically shuts down recording when the voltage falls below a specified voltage and cuts off the power to protect the battery of the vehicle.