



PLAY

interactive game table

Installation Instructions

- Open the crate.
- Lift out table top and place face side down on clean soft surface.
- Attach legs to top using bolts provided (4 per leg) using a T-25 star bit.
- One leg will house the 14' power cord. Connect the end of the cord to the table top before attaching the leg to the top.
- Connect the power cord to the building power supply.
- Turn the power on – the rocker switch is found on the underside of the table top.

- Begin to **PLAY**

Tools you will need:

Clean surface: Clorox Clean Ups work best



Cordless Power Drill



T-25 star bit