



2018-Current Honda Gold Wing DCT Clutch Initialization Procedure.

Note: This process is a Honda Service procedure and is recommended by Honda for all DCT Goldwings.

1. Transmission oil must be to full operating temp. Procedure will not work otherwise. A 5-10 minute ride will accomplish this.
2. Hold down "D" while turning on ignition switch. Do not start trike. Release "D" when engine check light goes off.
3. Push "D,D,N,D,N"
4. Transmission gear Icon will flash.
5. Start motorcycle normally. Motorcycle will go through a series of shifting and engine throttle operations automatically and then go into "TOUR" mode.
6. When "TOUR" mode shows on display, procedure is finished.
7. Turn off ignition switch and restart trike to ride.
8. CSC recommends doing this procedure after every oil change.