## **Adaptive Flipper Control**

Do I need a 2 Switch Button add on kit?

The Adaptive Flipper Control (AFC) was designed to be compatible with as many pinball machines as possible. This includes the standardization of the hand controller. Having a device that works on machines made in the 1950s and those made in the 2020's required some level of compromise. The following paragraph will help you figure out if your machine needs a 2 Switch Button Kit.

First remove the playfield glass and raise the playfield. You can prop it up or raise it to rest against the back box if your machine is capable of this. Look at the LEFT flipper button inside the cabinet. If there is only 1 switch controlled by that single button, then the LEFT side does not need the kit. Now look at the RIGHT flipper button inside the cabinet. If there is only 1 switch controlled by that single button, then the LEFT side does not need the kit.

You will need a 2 Switch Button add on kit for each button with more than one switch.

1 Switch Button



2 Switch Button



**Technical Support** 

We made every effort to ensure the installation of the AFC is a simple and straight forward as possible. However, we could not anticipate every condition that exists. We do provide email support and phone support, however unless you are extremely lucky to catch us at the warehouse/office, an email will be the best method to acquire assistance. If you do email, please include the Make/Name of your machine along with the problem you are having. Photos of the components in question are always good.

Website: www.AdaptiveGameProducts.com

Email: Info@gamepreservehouston.com

Phone: 281-203-8935