

Fire Door Guide for Tenants

Homeowners Care, Cleaning and Maintenance Guideline

Overview

We want to make your home better and safer. This guide will help you understand how to care for and maintain your fire door so it keeps you safe.

Key Instructions

1. Do not adjust or remove hardware

- Your door has special parts like the handle, lock, door closer, letter plate, and door viewer.
- Do not change or remove these parts. If you do, it will no longer be fire-safe.
- · If something needs fixing, tell your landlord.

2. Fire Rated Glass

- · The glass in your door is fire rated.
- If something needs fixing, tell your landlord as only an accredited person should fix it.

3. Fire Rated Seals

- · The door has seals that are fire rated.
- If any seals come loose, tell your landlord right away. Do not fix or replace them yourself.

4. Door Closer

- The door has a closer to keep it shut in a fire.
- Do not prop open, adjust, or remove the door closer. It needs to stay in place to keep you and your neighbours safe.
- Do not drill holes or attach items to your door as this can affect its fire safety.

Care and Maintenance

1. Cleaning the Door and Frame

- Clean the door and frame regularly with warm soapy water and dry with a soft cloth.
- Be careful not to disturb the sealant where the frame meets the wall.
- Extra care is needed if the door is near the coast or industrial areas because of corrosive elements.

2. Cleaning the Hardware

- For the lock and hinges, use a light spray of WD-40 PTFE silicone spray twice a year.
- For the letter plate, handle, and door knocker, wash with soapy water and dry with a soft cloth.
- Only use non-abrasive, neutral cleaning products to protect the hardware.

3. Avoiding Damage

- Do not use harsh cleaning methods, abrasive cleaners, scouring pads, high-pressure washers, or steam cleaners on the door or frame.
- Avoid using bleach or solvents like white spirit, methylated spirit, cellulose thinner, acetone, or nail varnish remover.
- Do not use adhesives or tack to protect or fix decorations on the door.
- Avoid long key chains or sharp objects that might damage the door.


If you have any concerns or need help with your fire door, contact your landlord immediately.





Fire Door Guide for Tenants

An overview of your fire door



Key Instructions:

Your door has been fitted with specific hardware including the handle, lock, door closer, letter plate and door viewer. In order to keep the fire rating intact, DO NOT adjust or remove these items, to do so would invalidate the fire rating. The glass used in your door is fire rated and assembled according to the certification requirements.

Support & Contacts

If you have an issues with your fire door please contact Birmingham City Council to arrange a call out.

