



CHILDTRAC

HOW TO DELETE PHOTOS FROM THE WATCH:


1: Go in Gallery



2) Go in Albums



3) Select photo



4) Click on the name



5) it will list the photos in small and then just swipe upwards and it will delete the photo

