



UNIVERSAL TENTS CUBE



www.pfbereg.com

CONTENT

Introduction.....	2
Specifications and equipment.....	3
Precautions and recommendations / Setup.....	4
Setup of the folding wall / Setup veranda / Setup of a partition in cuboid tent.....	5
Setup of metal inserts for the chimney exit.....	6
Tent features / Care and storage.....	7
Warranty.....	9
Accessories.....	10

The Production Factory Bereg team, which consists of hundreds of people involved in the creation of our equipment, thank you for the opportunity to do what they love the most.

Our mission is to create universal, reliable equipment that can withstand any weather conditions. These products that open up a new way of traveling with maximum comfort.

You are the main experts of the company. Your honesty and passion for adventure make our work special, and your feedback inspires us to create and improve our products! We are certain that with your support we will continue to innovate and provide top quality equipment. We promise not to stop there and implement new ideas that can expand the horizons of your travels.

Please write to us more often: you have a power in your hands that you don't even know you have! Your emails help the company grow and develop.

Thank you for inspiring us!



Tent Cube 2.20



Tents «Bereg» in the expedition
«The Baikal Project 2020»



Tent Cube Pentagon



Tent Cube 2.20

Since 2009 production Factory Bereg has accumulated a wealth of experience in the development, creation and testing of tents. The best ideas and materials are implemented in the CUBE series:



Use in all climatic zones under all temperature conditions.



Quick installation. The fly and the frame of the tent are a single structure. Umbrella type assembly mechanism.



The range of tents can accommodate from 3 to 14 people.



Folding wall, duplicated with a mosquito net. It is possible to install a veranda (optional).



Unique patented frame door.



Built in Stove Jack.



The frame is made of high-strength aviation alloy B95T1. The hub is steel.



Water resistance. Outer fly - PU 4000 mm, inner fly - PU 2000.

	Cube 2.20	Cuboid 3.60	Cuboid 4.40	Pentagon	Hexagon
Floor size LxW, m	2,20 x 2,20	3,40 x 1,70	4,40 x 2,20	3,45 x 3,45	4,65 x 4,65
Height, m	1,90	1,90	1,90	2,1	2,1
Floorage, m ²	4,84	6,48	9,68	8,33	12,57
Weight,kg	25	34,5	41	33	42,5
Flies, pc	2	2	2	2	2
Entrances, pcs	2	2	2	2	3
Windows, pcs	2	4	4	4	5
Floor	+	+	+	+	+
Chimney exit, pcs	1	2	2	1	1
Partition		+	+		
Capacity (max.), persons	up to 4	up to 6	up to 8	up to 7	up to 13
Packed size, m	1,75 x 0,3 x 0,3	1,3 x 0,3 x 0,3	1,7 x 0,3 x 0,3	2 x 0,3 x 0,3	2,25 x 0,3 x 0,3
Frame	Aviation aluminum alloy B95T1				
Rod diameter (roof/walls), mm	10	10	10	10	10 / 12
Waterproof (outer fly/inner fly)	Oxford 300 PU 4000 / 240 PU 2000				

EQUIPMENT

Tent.....1pc
 Pegs.....1set
 Rope.....1set
 Dome net shelf.....1-2pcs
 Transparent window with velcro.....1-4pcs

Bag.....1pc
 Poles for folding wall.....4pcs
 Poles (for Pentagon and Hexagon).....1pc
 Instruction and warranty card.....1pc
 Spare parts kit*.....1pc

***Repair kit includes:**

mechanism repair bolt, plastic buckle, fabric piece for tent repair.



Universal use: winter living tent, fishing tent, hunting tent, summer tent.



Entrances and windows are equipped with a mosquito net.



Efficient ventilation system.



Convenient transport.



Seams of the outer tent and floor processed a sealing tape.



Wind resistance. Reinforced wind braces are connected to the frame.



A wide range of additional accessories.



The warranty on the frame and fly - 2 years.

!! PRECAUTIONS AND RECOMMENDATIONS

4

- When installing and reassembling the tent, be careful with the frame elements to avoid injury.
- Secure the tent with guy lines to the pull loops on the tent.
- In windy weather, do not place the tent near trees.
- Do not use the tent when the wind is above 17 m/s.
- Ensure continuous ventilation in the tent.
- Provide an unobstructed exit from the tent.
- Do not use gas, gas equipment and liquid fuel devices in the tent!
- Do not use open sources of fire in the tent.
- When setting up the tent, keep it a safe distance from open sources i.e. campfires.
- Do not allow the use of persons under the influence of any substance.
- Do not allow children to use without adult supervision.

The users are personally responsible for their safety.

TENT SETUP

Visual inspection.

Make sure the tent is not damaged.

1-2. Preparing for setup. Arrange the tent so that the roof is facing up. The difference between the roof is the absence of a pull loop.

3. Spread the roof evenly.

! Follow the assembly sequence: first all the side walls, then the roof! Incorrect assembly order can cause damage to the frame.

4. Opening the walls. Pull on the loops in the center of any side wall until the frame is fixed in the working position. Similarly, install all the side walls.


! When installing in windy conditions attach one wall with the help of braces.

5. The opening of the roof. Enter the tent. Open the roof up until the frame is fixed.

! The Pentagon and Hexagon tents are equipped with a center support pole to strengthen the roof, as well as a handle for assembly, which are screwed into the central mechanism. The center pole is important for use in down drafts and snow load.

6. Positioning the tent. Stretch the tent using the pull loops on the walls, attach the guy lines and secure the skirt with stakes.


At the end of use, close the zippers of windows, doors and fold the tent in reverse order.



5

SETUP OF THE FOLDING WALL

- Unzip the zippers on the folding wall and lift it up.
- Install the two support posts in the special pockets - **No. 1.**
- Secure the folding wall with a guy line. To stiffen the structure, install two support posts in the pockets on the side walls - **No. 2.** Attach the tent to the poles with velcro - **No. 3.**
- Fix the lower part of the frame with the strap and buckle - **No. 4.**



SETUP VERANDA

- Fix the veranda with the toggles in the corners of the folding wall - **No. 5.**
- Secure the veranda with velcro around the perimeter of the folding wall - **No. 6.**
- Secure the veranda to the support posts with velcro - **No. 7.**



SETUP OF A PARTITION IN CUBOID TENTS

The inner tent is equipped with a removable partition with a door that divides the tent space into two rooms.

- The partition is attached with two zippers - **No. 1** and **No. 2.** One zipper connects to the walls and ceiling, the second - to the floor.
- Fasten the zipper, carefully holding the partition. The partition door is equipped with a mosquito net with the possibility of fixing in the open position.



SETUP STRAP IN CUBOID TENTS

To eliminate the accumulation of precipitation in the central part of the roof, the tents are equipped with a strap.

Installing strap:

- Connect the two ends of the strap with the reinforced buckle;
- Tighten the strap until the roof takes a streamlined shape.

* In double-layer tents, the strap is located between the inner and outer tent. To access it, use the zippered openings.

SETUP OF METAL INSERTS FOR THE CHIMNEY EXIT

6

The chimney exit is intended for the chimney pipes of the wood stove. The Bereg tents are equipped with 1 chimney exit.

The chimney exit is completed with one or two metal inserts - one for the inner tent and one for the outer tent.

- The inserts are removable, so they do not damage the tent material during long-term storage, transportation and frequent assembly and disassembly.
- The insert also helps maintain an airtight connection with the pipe, which reduces the precipitation into the tent.

1.

When you install the tent, you will find that there is no metal ring in the chimney exit - metal inserts are **included for the use with the stove.**

2.

To fully use the wood stove, **you need to install a metal insert in the opening on both the inner and outer tent.** This is necessary for the safe use of a wood stove.

3.

Installation on the inner tent. There is a hole in the upper part of the chimney pocket. Slide the insert inside the pocket so that the hole in the insert matches the hole in the fabric as much as possible. Repeat the procedure on the outer tent.

4.

After completion of use, remove the metal inserts from the outer and inner tents, and store them in the tent bag.




TENT FEATURES



OUTER FEATURES

- 1. Zippered entrances and windows** with mosquito nets.
- 2. Folding wall** with support racks.
- 3. A partition on a folding wall** with a rectangular entrance and a mosquito net.
- 4. Built in Stove Jack** to use additional equipment.
- 5. Multifunctional viewing windows** with transparent velcro lining.
- 6. Guy line points.** Connected to the frame. Equipped with reflective elements.
- 7. Additional tie-down loops** on the tent skirt.
- 8. Ventilation window** for fresh air supply.



INNER FEATURES

- 9. Organizers attached with velcro (option).**
- 10. Shelf-mesh.** Useful device for installing a flashlight and drying things.
- 11. Zippered floor.** It is installed at a height of 10 cm.
- 12. Zippered partition in Cuboid.** Is mounted on the inside of the tent. Equipped with a door with a mosquito net.
- 13. Fixed sectional pockets.**
- 14. Carabiners for attaching equipment.**

CARE AND STORAGE

Tent



It is recommended to clean the fly and frame from sand and dirt after use. Do not use abrasive or hard brushes.



Dry after use.



Store in a dry place.

Flies



The flies are attached to the frame with velcro and ties. Undo the tent if necessary.



Hand wash only. Do not rub, do not squeeze.



Cold water wash, max. temperature 30°.



Do not iron.

REPAIR



Tent flies: fabric and glue.



The restore seam seal: PU-based adhesive.



WARRANTY CARD



Cube
2.20



Cuboid
3.60



Cuboid
4.40



Pentagon



Hexagon

Seamstress

Sewing date

Date of manufacture

_____/____ " ____ " ____ 20 " ____ " ____ 20

S.P.

Specialist of the TCD

Master of the TCD

_____/_____

_____/_____

Seller

Date of sale

_____/_____

" ____ " ____ 20

S.P.

The manufacturer offers a 2-year warranty for flies and for frame free repair in case of defects due to manufacturing issues.

The warranty does not cover damage caused by improper and careless storage or operation or non-compliance with care instructions and precautions.

The manufacturer is not responsible for damage to the product that occurred during its transportation to the customer location, or for any damage from normal wear and tear or natural disasters (sudden exposure to natural phenomena and mechanical effects of unforeseen physical forces).

The warranty provided is in the form of a warranty card and a delivery note with a stamp.

The manufacturer of the goods reserves the right to make changes in the characteristics and equipment of the goods without prior notice to the buyer. **The data on the site is for informational purposes only and are not a public offer.**

1. Veranda with a mosquito net is a useful accessory for increasing the area of the tent. Materials - Oxford fabric PU 300 to 4000 and a mosquito net. The veranda walls have a lifting structure and equipped with a central entrance.

2. PVC floor provide 100% waterproof. Interchangeable with standard floor.

3. Insulated floor is designed to provide additional insulation from the cold and create comfort.

3.1 Section of insulated floor in the tent (2,4 x 1,2 m). Applicable for Cube 2.20, Cuboid 3.60 and Cuboid 4.40. The number of sections depends on the size of the tent. The segments are connected by a velcro. Partial floor covering is possible. Can be used as a camping mat.

3.2 Insulated floors for the tents Pentagon and Hexagon has the appropriate tent size and shape.



MORE PRODUCTS



UP tents



Wood-burning stoves



Sauna tents



Marquee tents



Airboats, boats PVC



Camping furniture



www.pfbereg.com
sale@pfbereg.com
service@pfbereg.com