






# FUELLink ST Fuel Management System



## FUELLink ST Dimensions

This guide is to show the dimensions of a pedestal mounted FMS, a wall/tank mounted system will require the dimensions of the pedestal to be removed.

# FUEllink ST Fuel Management System



## **Pedestal Mount Example**

Shown above is a FUEllink pedestal mounted FMS. The base plate comes with mounting holes pre-drilled for ease of fitting. Pedestal is easily removed from inside the FMS head through a series of bolts to secure it in place.