

ELECTRICAL PARTS

IMAGE	NAME	OE NO. FOR REF ONLY	MODEL	DH PART NO
	Starter Switch saddle mount	1925781		U3001
	Light Switch, 3-Position	70208197		U3002
	Worklight 12 Volt red	S 42792		U3003
	Kubota Cylinder head 1902		Kubota Cylinder head 1902	59001
	Kubota Cylinder head 2203		Kubota Cylinder head 2203	59002
	Kubota Cylinder head V1702		Kubota Cylinder head V1702	59003