


WELL BUBBLER 10-120 TELEMETRY OUTPUT WIRING DIAGRAM



NOTES
0-5V output is active, does not require external excitation. This output is not isolated, and referenced to system battery
4-20mA is passive, and requires external 12-36Vdc excitation. This output is galvanically isolated from all other inputs, outputs and battery supply

DRAWING	Well Bubbler 10-120 Telemetry Output Wiring Diagram		
VERSION	1.0	PAGE	1 OF 1
DATE	02/05/19		
DRAWN BY	A. BUGROV		

WIRING INSTRUCTIONS		
WIRE	COLOR	TERMINAL
5V OUT POS +	N/A	1
5V OUT NEG -	N/A	2
4-20mA OUT NEG -	N/A	3
4-20mA OUT POS+	N/A	4