



ORBITER EXPRESSION PEDAL

PEDAL - Typical expression operation. No surprises here except that virtually any number of Orbiter Pedal's can be added to the network to cover any position on stage or off.

TOE SWITCH + RED LED - Easily visible indicator illuminates when the toe switch is operated. Latching/Momentary option is chosen on Control Station. When latching is selected, the LED will light when switch is remotely operated and in the CLOSED position. While in Momentary mode, each pedal will flash to indicate a successful message sent to the Control Station. Every pedal in the network will reflect the current status of the switch.

ENGAGE - Power switch on left side of pedal is easily operated by hand or foot. Power indicator LED is at back of pedal below the heel and lights the approach to the pedal.

DC JACK - Typical 9V DC Center Negative. The Green LED will illuminate when the battery has been fully charged.