

# Brushes (cleaning)

# B

The bobbin and underneath the needle plate require regular cleaning. There will normally be a small brush supplied with your machine for this purpose.

