Edge Stitch Foot



The Edge Stitch Foot is used for stitching in the ditch, edge stitching, as well as joining two edges together. It is often used when sewing patchwork as the centre guide in the foot can keep the sewing straight as the two pieces are joined (also known as stitch in the ditch).





www.sheilassewingschool.com