Suede Brush

S

The Suede Brush is brass wired with a wooden handle and cleans all items of suede. Sweep the brush over the article of suede to loosen and remove dirt trapped in the suede fibres. Brushing in multiple directions can help restore the overall nap to suede.





www.sheilassewingschool.com