

# DT12 - Auto Neutral

**Feature:** The TCM (Transmission Control Module) automatically shifts the transmission into neutral to prevent unintended movement if:

- The truck is left in gear, and tractor parking brake is applied or
- The ignition switch is turned off, with the truck left in gear

**Once Auto Neutral is activated, the gear selector must be returned to the neutral position before the transmission can be put back into gear.**



## Auto Neutral Alerts:

- If the parking brake is applied while the transmission is in gear, the dash will flash “N” for neutral for 5 seconds and a quick “beep” will sound
- After an additional 5 seconds, a second “beep” will sound and the DT12 will shift into neutral