

DT12 – Creep Mode

Creep Mode

Feature: The transmission simulates a torque converter in an automatic transmission. The vehicle will slowly creep in Drive or Reverse until service brakes or accelerator pedal are depressed.

Benefits:

- Improves low speed maneuverability for parking, docking, heavy traffic, or other low speed situations.
- Activated when service brakes are released.
- Although the clutch slips to transfer limited torque, the Transmission Control Module (TCM) constantly monitors load and temperature.
- Transmission will not allow the clutch to be damaged by Creep Mode, and will abort if damage is imminent

Interactive Dash Messages:

