


If there is an error....



Unavailable Alert



ABA Unavailable



If the radar stops working, there will be several alerts on the instrument cluster indicating that ABA (Active Brake Assist) and ACC (Adaptive Cruise Control) are not available. Although ACC is disabled, **regular cruise is available by tapping the cruise button twice**



The radar is “self-healing”. If it becomes inoperable due to a physical obstruction, removing the obstruction will result in the radar coming back online with no further action on the driver’s part.