

Summer Use

Open front of Trap house. Stay to the side, do not go directly in front.

Turn on power to all 5 Green transceivers.

Turn on power to Scorekeepers transceiver.

(Powers off after 2 minutes of inactivity)

Insert card

When finished close up trap house. Power down 5 transceivers and return Scorekeepers Transceiver to file box located in shelter.

Remove your target card.

(More detailed operating information can be found on Website.)

Winter Use

Open front of Trap house. Stay to the side, do not go directly in front.

Roll out cord and attach, foot or hand pull.

Insert card

When finished roll up cord and close up trap house.

Remove your target card.