

Motion eTravel

Parts List



Contents



Front

Page 3



Rear

Page 4



Seat

Page 5



Batteries


Page 8



Front Parts	Part Number
1 Upper Tiller Shroud (Black)	ET.101
2 Upper Tiller Shroud (Blue)	ET.102
3 Upper Tiller Shroud (Red)	ET.103
4 Horn	ET.104
5 Horn Button	ET.105
6 Key Barrel	ET.106
7 Lower Tiller Shroud (Black)	ET.107
8 Lower Tiller Shroud (Blue)	ET.108
9 Lower Tiller Shroud (Red)	ET.109
10 Tiller Bar	ET.110
11 Front Shroud (Black)	ET.111
12 Front Shroud (Blue)	ET.112
13 Front Shroud (Red)	ET.113
14 Foot Pad	ET.114
15 Front Wheel	ET.115
16 Hub Cap	ET.116
17 Controller	ET.127
18 Main Controller Cable	ET.131
19 Speed Pot	ET.132
20 Front Chassis (w/ Bearing & FWFT)	ET.133



Front Parts	Part Number
21 Front Wheel Fixing Tube	ET.134
22 Tiller Adjustment Assembly	LL.107
23 Basket	LL.110
24 Speed Knob	LL.121
25 Wig Wag	LL.122
26 Key	LL.126
27 Voltmeter	LL.127
28 Throttle Pot	LL.128
29 Basket Bracket	LL.140
30 Tiller Adjustment Knob	LL.141
31 Rear Chassis Connector (Female)	LL.148
32 Battery Connector (Male)	LL.151
33 Wheel Bearing	LL.158
34 Handle Grips	LL.166



Rear Parts	Part Number
35 Rear Chassis	AS.108
36 Rear Wheel	ET.121
37 Rear Shroud (Black)	ET.122
38 Rear Shroud (Blue)	ET.123
39 Rear Shroud (Red)	ET.124
40 Motor	ET.128
41 Electromagnetic Brake	ET.129
42 Transaxle	ET.130
43 Anti-Tip Wheel	LL.117
44 Rear Chassis Connector (Male)	LL.147



Seat Parts	Part Number
45 Seat Plate	ET.117
46 Seat Assembly (w/ Plate & Knob)	ET.118
47 Seat Cover (Base)	ET.119
48 Seat Cover (Back)	ET.120
49 Seat Post	ET.125
50 Left Armrest	LL.111
51 Right Armrest	LL.112
52 Seat Post Pin	LL.116
53 Armrest Securing Knob (set)	LL.144



Battery Parts	Part Number
54 Battery Charging Port	AL.123
55 Battery Charger (2ah)	ET.126
56 Battery Box (only - no batteries)	ET.135
57 EU Battery Charger	ET.136
58 Battery Pack Complete (w/ batteries)	ET.137
59 Circuit Breaker	LL.119
60 Battery Connector (Female)	LL.149