



SYNERGISE



Installation instructions for Synergise soap dispenser

Box Contents:

- 1 Dispenser
- 1 Opening Key
- 4 Fitting Screws and Plugs

Tools Required:

- Drill
- Screwdriver

1



Open the unit with the key provided.

2



Remove the reservoir and put to a side for installation.



Remove the reservoir & pump. Mark & screw the unit to the wall making sure to screw in the pump support in the correct position for either liquid or foam.



6

Reattach the reservoir and fill it with the relevant product to the pump supplied.



Close the dispenser then the unit will now be operational.