

Thank you for your purchase from a New York City business

IMPORTANT: SEPARATE FIRMWARE UPDATE FOR RIGHT AND LEFT controller

YOUTUBE LINK: https://youtu.be/2eWW_oCFxkc

DOWNLOAD THE FIRMWARE UPDATE

a. from WWW.NEXILUX.COM - DRIVERS

RIGHT Controller:

1. Open the upgrade tool & click OPEN to import the firmware file.
 - a. Select the file: switchMAC_2020_07_24_R.jocn
2. Press the Joystick until 2 LED light up and Turn off. Release the Joystick
3. Use the USB Type-C cable to connect the controller with PC & click DOWNLOAD
Firmware will be successfully updated when the progress bar reaches to the right.

LEFT Controller:

1. Open the upgrade tool & click OPEN to import the firmware file.
 - a. Select the file: switchMAC_2020_07_24_L.jocn
2. Press the Joystick until 2 LED light up and Turn off. Release the Joystick
3. Use the USB Type-C cable to connect the controller with PC & click DOWNLOAD
Firmware will be successfully updated when the progress bar reaches to the right.

Thank you for your purchase from a New York City business