

## WEAR OPTIONS



There are several methods of wearing the G-SAFE depending on the accessory you selected. If you need accessories contact us.



Velcro attachment for wearing on the belt



Armband Velcro attachment



Wrist silicone bracelet

## TURN THE WEARABLE ON AND OFF



**To start using the G-SAFE:**  
Disconnect the USB cable behind the G-SAFE



**Start the G-SAFE:**  
Press the bottom button on the side until you hear a 'beep' and feel a vibration



The screen will light up and display the percentage (%) of remaining battery, cell signal strength, and the current date. The G-SAFE is now ready for use.



**At the end of the shift,** connect the device to the charger cable provided for charging, so that it is at 100% and ready for the next use. If you do not use the device for a period longer than 48 hrs, you can turn it off if not shut off already.

## ALERT PROCEDURE



**SOS**



**SOS Alert:**  
Press the SOS button for 3 seconds. You will hear a beep, vibration and see the SOS indication on the screen, which indicates that the notification alert is in progress. If the connection allows it, a call to the answering party will be made.



**FALL DETECTION**



If the G-SAFE detects a fall, it will emit a 'beep' and display MD on the screen. If the connection allows it, after a few seconds, a call will be made to the answering party will follow. All alerts will be sent to responders.