

**Acutabove Woodworking
Fraction Calculator**

Adding: Start with "Zero" in the display window.
Place pencil in the hole adjacent to the first fraction.
Rotate dial clockwise until the pencil hits the stop arm.
Place your pencil in the hole adjacent to the next fraction.
Rotate the dial clockwise until the pencil hits the stop arm.
The answer will be displayed in the window.
You can continue to add fractions by placing the pencil in the fractions to be added and rotating clockwise until the pencil hits the stop bar.
If the "Zero" point passes the window, add "1" to your answer.



Subtract Fractions: Start with "Zero" displayed in the window
Place a pencil in the hole adjacent to the first fraction.
Rotate clockwise until your pencil hits the stop bar.
Place pencil in hole adjacent to your answer window.
Rotate the dial counter-clockwise and stop at the fraction to be subtracted.
The answer will be displayed in the window.
If the "Zero" passes the window, subtract 1 from the answer.

